


Worm Gear Manual

- /// Page 2 Design of the worm gear
- /// Page 3 Mounting instructions
- /// Page 4 Operating instructions and choice of oil
- /// Page 5 Unique gear number
- /// Page 6 Spare parts diagram
- /// Page 7 Spare parts list
- /// Page 8 Declaration of incorporation



Design of the Worm Gear





Mounting instructions

This instruction applies for BJ worm gears size 42, 52, 61, 79 and 99. All according to our catalogues. Mounting and taking into service shall be done by trained and/or skilled personnel.

Field of application

Unless otherwise agreed, the gears may be used in ambient temperature between 0 and +40 ° C and in normal atmosphere and normal atmospheric pressure.

If the gear is used in dusty or dirty environment, be sure that ingress in glands is avoided. The same goes for outdoor use or wet environment.

Before mounting

- Examine the gear for damages and leakages.
- Ensure that the unit corresponds to the ordered.
- Some units are deliberately delivered without oil. If this is the case it is clearly marked. If the unit is delivered without oil, be sure to fill it with the right type and amount according to catalogues (can be found at www.bj-gear.com and on page 4).
- If possible, make a test run of the unit before mounting. (see page 4).
- If the unit is delivered with motor, electromagnetic brake or coupling, encoder etc., be sure to follow the operating instructions for these.
- Be sure that it is not possible to start the unit unintentionally during mounting.
- Before mounting the unit in the application, be sure to secure parts that could move unintentionally and make harm or damage. Please observe that not all units are self-locking.
- Be sure that the mounting planes are stable, clean and plane.

Mounting of motor:

- Be sure that there is mounting grease between the motor shaft and the hollow input shaft of the gear.
- The gear input shaft should be pre-greased at delivery.
- Do not use hammering or excessive force during mounting of the motor. It can damage the bearings in the unit.
- If the motor and unit are connected by a coupling, be sure that the alignment is within the specifications of the coupling.

Mounting of other accessories (brake, encoder etc.):

- Be sure to follow the operating instructions for these.
- Especially for brakes and clutches, be sure that no dirt, dust, oil or grease is present on or between any friction elements.

Mounting:

- Use only the holes or threads of the unit that is intended for mounting.
- Do not make changes to units unless approved by BJ-Gear.
- If torque arm is used, be sure not to over-constrain.
- Be sure to mount it in such a way that sufficient cooling is provided. If gear or motor is provided with cooling fan, be sure that sufficient air flow is accessible.
- Do not use hammering or excessive force during mounting.
- Be sure that the drive shaft and the driven shaft are properly aligned.
- If the gear is supplied with air vent screw, be sure to position the gear in such a way that it is placed above the oil level. If the gear is delivered with a transport screw, be sure to interchange the transport screw with the air vent screw. Do not use a motor with higher power than allowed according to catalogue or documentation.
- Do not load the gear with higher torque or forces than allowed according to catalogue or documentation.
- Mount the gear in such a way that vibrations are minimized or eliminated.
- Secure screws so they don't get loose.
- Be sure to place feather keys where needed.

Operating instructions

Starting up:

Before starting up the gear be sure that:

- The motor is properly secured to the unit.
- The gear is properly secured to the application.
- Test the functionality of electric brakes, couplings or safety devices, if such are installed.
- Brakes and couplings are released.
- Tools, wiring, clothes etc. are removed from moving part.
- When starting up, do it as gently as possible.
- Observe closely that the intended function occur, and if not, shut down the system and search for errors in a safe way.
- If unexpected noise or vibrations occur shut down the system and search for errors in a safe way.
- When the gear has reached its operation temperature, examine for leakages.

Running-in:

The lifetime of the gear will improve if is run in properly. A proper run in is as follows:

- Run the gear for about 15 minutes in each direction with no load.
- Let the gear cool down.
- Start it up and load it with app. half the torque. Gradually increase to full torque. Do this in both directions.
- It is not always possible to do it this way but some running in is better than none.

Choice of oil and oil quantities

Oil change

The gears are lubricated for life. However, gears being exposed to heavy load should be subjected to oil change approx. every 5 years. Gears running in very hot environments may require oil change every year. **Do not mix** synthetic oils and mineral oils. All indicated outputs are based on synthetic oils.

Oil quantities


Series 42	Series 52	Series 61	Series 79	Series 99
0.06 liter	0.18 liter	0.21 liter	0.5 liter	1.1 liter

Description	Application	Viscosity	Oil
Fully synthetic gear oil, Standard	Normal load and ambient temp. -25° to +40°C	220	Klübersynth GH 6-220
Fully synthetic gear oil	Heavy load and ambient temp. -20° to > +40°C	460	Klübersynth GH 6-460
Fully synthetic gear oil	Heavy load and ambient temp. -20° to > +40°C	680	Klübersynth GH 6-680
Liquid grease	Normal load and ambient temp. -40° to > +40°C	1200	Klübersynth GE 46-1200
Special lubricating oil for food and pharmaceutical industries	Normal load and ambient temp. -20°C to +40°C	460	Klüberoil 4 UH1-460 N

Ambient temperatures are guide values which depend on the lubricant's composition, the intended use and the application method.

Read more on www.klubersolutions.com

Unique gear number




Unique gear number


The unique serial numbering of the product means that we can always identify the worm gear and supply the correct spare parts. If there is a need for a replacement product, we can always reproduce a worm gear by using the unique serial number, no matter what degree of specialization and whenever it was originally delivered.




Spare parts diagram




Housing Type 1



Housing Type 2



Housing Type 3





Spare parts list

1	Bearing Cover	22	Parallel key B
1A	Side Flange	23	Parallel key A
2	Gasket	24	Parallel key A
3	Screw	25	Locking Ring
3A	Bolt	26	Washer
3B	Screw	27	End Cover, open
4	Screw	28	End Cover, closed
5	Oil Seal	29	Gasket
6	Oil Seal	30	Motor Flange
7	Oil Seal	31	Bearing Cover
8	Oil Seal	31A	Side Flange
8A	Oil Seal	32	Stud Cover
9	Ball Bearing or Tapered Roller Bearings	33	Screw
10	Ball Bearing or Tapered Roller Bearings	35	Gearbox, type 1, for Hollow Output Shaft
11	Ball Bearing or Tapered Roller Bearings	36	Gearbox, type 1, for Double Free Output Shaft
12	Ball Bearing or Tapered Roller Bearings	37	Gearbox, type 1, for Free Output Shaft
13	Worm Wheel	38	Gearbox, type 2, with Support, Worm at Top, for Hollow Output Shaft
14	Worm Wheel	39	Gearbox, type 2, with Support, Worm at Top, for Double Free Output Shaft
15	Spacer Ring	40	Gearbox, type 2, with Support, Worm at Top, for Free Output Shaft
16	Spacer Ring	41	Gearbox, type 3, with Support and Worm at Bottom, for Hollow Output Shaft
17	Hollow Output Shaft	42	Gearbox, type 3, with Support and Worm at Bottom, for Double Free Output Shaft
18	Double Output Shaft	43	Gearbox, type 3, with Support and Worm at Bottom, for Free Output Shaft
19	Single Output Shaft	44	Locking Ring
19A	Single Output Shaft, extended		
20	Hollow Worm Shaft		
20A	Hollow Worm with Free Shaft		
21	Free Worm Shaft		
21A	Double Free Worm Shaft		



Declaration of incorporation

The below mentioned manufacturer and authorized to produce technical documentation for the partly finished machine, and in response to a reasoned request, transmit relevant information regarding the partly finished machine:

BJ-Gear A/S

Niels Bohrs Vej 47
DK-8660 Skanderborg
Tlf: +45 87 40 80 80
Fax: + 45 87 40 80 81
bj@bj-gear.com

hereby declare that the partly finished machine:

Gears and gear motors: Worm gears both BJ and LJ series, Strong helical gears, Strong spiral bevel gears, actuators og spindle gears, configured and ordered according to our standard catalogues

are produced in accordance to machinery directive 2006/42/EC annex II B og annex VII B.

Relevant standards used:

EN ISO 12100-1:2005
EN ISO 12100-2:2005

The partly completed machine must not be put into service until the final machinery in which it is to be incorporated has been declared in conformity with the provisions of machinery directive 2006/42/EC.

Stilling, 19.01.2010

Jesper Olesen
R & D Manager